



# TRK-SR1 QUICK INSTALLATION GUIDE

INSTALLATION: BEFORE BEGINNING MAKE SURE YOU HAVE ALL PARTS LISTED IN FIG. 1!



1. Clean installation surfaces using supplied alcohol cleaning towelettes.
2. Place installation templates on window as shown in Fig 2. (Note: Antenna cannot be mounted on front windshield)
3. Remove Red Plastic covering from adhesive on the main antenna unit and affix to window. (Fig 3.)
4. Place the other installation template on the inside window making sure the two templates are aligned properly with each other. (Fig. 4)
5. Connect the ThruGlass Internal coupler leads. Red line to a **constant** power lead (i.e. battery), Black line to ground, Satellite and Terrestrial lines to the XM Receiver. (Fig. 5)
6. Turn XM radio unit on.
7. Remove red plastic covering from adhesive on the Thru Glass internal Coupler and affix it to window. (Note: LED light will illuminate when power is on)




(Fig 1)




(Fig 2)



(Fig 4)



(Fig 5)




For TERK Tech Support visit [www.terk.com](http://www.terk.com) or Call 1-800-942-TERK (8375)


# TRK-SR1

## TIPS & PRECAUTIONS:


1. When choosing a location to mount the antenna, make sure that there is no metal including defroster lines and window tint in the center of the antenna unit! (Fig. 1) Any metallic based window tint must be cut away to allow for clear connection.
2. Make sure the surface where the antenna is to be mounted is as flat as possible and is completely cleaned using supplied alcohol pads. Any dirt and excessive curvature can cause the antenna to fall off in extreme conditions.
3. Choose a location on the vehicle's window that will allow the antenna's mast to rise above the vehicle's roof line.
4. Make sure antenna's mast or whip is pointed straight up to sky or perpendicular to the ground.
5. **Never place outside antenna and internal ThruGlass coupler together without glass between them. Doing this when unit is powered will damage the antenna!** (Fig. 2)
6. Make sure the red power line is connected to a **constant** power lead (i.e. battery) and the black line is chassis grounded.
7. The brightness of the LED light does not indicate signal strength. Be sure to align the Installation Templates to each other for maximum reception. (Fig. 3)
8. When pressing the TRK-SR1 onto the vehicle's window, apply an initial contact force of 15 to 20 PSI (steady finger-tip pressure) for 60 seconds. Allow 20 minutes for the adhesive to set before driving the vehicle. After installation, avoid running the vehicle through a car wash for 72 hours.
9. If XM Radio displays "Antenna" or "Check Antenna", check antenna connections to the XM receiver. If XM Radio displays "No Signal", the vehicle may be in an area where the XM Signal may be too weak. Move vehicle outdoors or to a location which has fewer buildings. If you are experiencing any other problems or require spare adhesive pads call 1-800-942-TERK (8375).



(Fig 1)



(Fig 2)



(Fig 3)



For TERK Tech Support  
visit [www.terk.com](http://www.terk.com) or  
Call 1-800-942-TERK (8375)



SATELLITE  
RADIO

# TERK