

Programming Factory Security on GM Cars and Trucks

Instructions for programming the GM factory security systems that do **NOT** disarm from the driver's door key cylinder. This programming is for the cars and trucks listed below.

- 96+ Camaro
- 96+ Firebird
- 99+ GM Trucks
- 99+ GM Sport Utility Vehicles

Step #1 Turn the ignition on then off.

Step #2 Remove the radio fuse only (not the fuse that says acc/radio).

Step #3 Turn the key to the accessory position. When you do this you will get **two chirps** from the door buzzer. Should you hear only one chirp, your vehicle does not have factory security and these instructions do not apply. **You need to hear two chirps.**

Step #4 Press the **unlock switch** on the door. This will give 1-4 chirps depending on the program step. Continue pressing the **unlock switch** until you get to the desired chirp setting.

- 1 Chirp – Security off
- 2 Chirps – Remote Only
- 3 Chirps – Factory Setting
- 4 Chirps – Passive Arming

Step #5 Turn the ignition off.

Step #6 Put radio fuse back in.

IMPORTANT: This wiring information is being provided free of charge on an “as is” basis, without any representation or warranty. It is the dealer's responsibility to verify any circuit before interfacing with it using a digital multi-meter. Directed Electronics Inc. assumes no responsibility with regards to the accuracy or currency of this information. Proper installation in every case remains the responsibility of the installer. Directed Electronics Inc. assumes no liability or responsibility resulting from an improper installation, even in reliance of this information.