

Toyota Tacoma 2007

WIRE	COLOR	LOCATION	POL.
Battery 1	White/Blue	Ignition Harness	Positive
Battery 2	White/Red	Ignition Harness	Positive
Ignition 1	Black/Red	Ignition Harness	Positive
Ignition 2	Blue/Yellow	Ignition Harness	Positive
Starter 1	Green/Black	Ignition Harness	Positive
Starter 2	Black/White	Ignition Harness	Positive
Parklights Positive	Green	White 13 Pins Conn. At Left Of Fuse Box Pin 10	Positive
Parklights Negative	Green	At Light Switch	Negative
Brake Lights	Blue	White 13 Pins Conn. At Left Of Fuse Box Pin 13	Positive
Horn	Green/Red	White 13 Pins Conn. At Right Of Fuse Box Pin 10	Negative
Tach	Black/White	Diagnostic Connector	6 Cyl.
Lock	Gray	White Connector (In driver's Kick panel)	Negative
Unlock	Blue/White	White Connector (In driver's Kick panel)	Negative
E-Brake	Lt.Green/White	At E-Brake Switch	Negative
Clutch	Black/White	At Clutch Switch Harness	Positive
Disarm	Green/Black (1)	White Connector (In driver's Kick panel)	Negative
Rearming	Purple	White Connector (In driver's Kick panel)	Negative
KeySense	Green/Black	At Ignition Switch	Negative
Door Pin FL	Green/Yellow	Back Of Fuse Box In A White 20 Pins Conn. Pin 2	Negative
Door Pin RL	Pink/Black	Back Of Fuse Box In A White 20 Pins Conn. Pin 5	Negative
Door Pin FR	Red/Black	Back Of Fuse Box In A White 22 Pins Conn. Pin 8	Negative
Door Pin RR	Pink/Black	Back Of Fuse Box In A White 20 Pins Conn. Pin 5	Negative
Fuel Pump	Black/Red	In A White 18 Pins Conn. At Driver's Kick Panel	Positive
VSS	Purple/White	Left Of Fuse Box In A Black Connector	AC
Head Lights	Pink	At Light Switch	Negative
Wiper Protection	Blue	At Wiper Switch	Open
BackUp Lights	Red/White	In A Gray Connector At The Drivers Kick Panel	Positive

IM/OM Compatibility

- OM-CUT-II (310-908-500) - OM-CUT-3 (310-907-516) - OM-FOT-1 (310-907-580)

Comments :

Note :This vehicle may be equipped with a immobilizer system that needs to be bypassed,(transponder)

(1) First pulse will unlock driver's door only, second pulse will unlock all the other doors.

This data sheet is supplied as information purpose only. Astroflex does not, in any way, warrant accuracy of the data. Before attempting any installation or connections, the installer should verify all wires with either a multi-Meter or a high level probe that is computer and air bag safe. At all time, the installer assumes all damages, defects, or all other problems that could be linked to the installation process. ©Astroflex, 2003. All rights reserved.
La présente feuille de données est fournie à titre informatif seulement. Astroflex ne garantit d'aucune façon la justesse de ces données. Avant de procéder à l'installation ou de faire tout branchement, l'installateur doit vérifier tous les fils à l'aide d'un multimètre ou d'une sonde à haute impédance sécuritaire tant pour l'ordinateur que le coussin gonflable du véhicule. L'installateur assume en tout temps, l'entière responsabilité de tous dommages malfaçons ou autre résultant de l'installation. ©Astroflex, 2003. Tous droits réservés.

Toyota Tacoma Harness From Driver's Door



This data sheet is supplied as information purpose only. Astroflex does not, in any way, warranty accuracy of the data. Before attempting any installation or connections, the installer should verify all wires with either a multi-Meter or a high level probe that is computer and air bag safe. At all time, the installer assumes all damages, defects, or all other problems that could be linked to the installation process. ©Astroflex, 2003. All rights reserved.
La présente feuille de données est fournie à titre informatif seulement. Astroflex ne garantit d'aucune façon la justesse de ces données. Avant de procéder à l'installation ou de faire tout branchement, l'installateur doit vérifier tous les fils à l'aide d'un multimètre ou d'une sonde à haute impédance sécuritaire tant pour l'ordinateur que le coussin gonflable du véhicule. L'installateur assume en tout temps, l'entière responsabilité de tous dommages malfaçons ou autre résultant de l'installation. ©Astroflex, 2003. Tous droits réservés.