



2002 & UP CARAVAN/TOWN & COUNTRY MULTIPLEX INTERFACE FOR REMOTE START

This vehicle requires the circuit below to install a Remote Start. The Data wire is Violet with a Brown Stripe and is located at the ignition switch harness. This wire must be interrupted with a relay and a 180 Ohm Resistor. If this Bypass is not installed when doing a remote start, the vehicle will crank but not start.

