

Ford Taurus 2008

WIRE	COLOR	LOCATION	POL.
Battery 1	Red	At Ignition Switch	Positive
Ignition 1	White/Orange	At Ignition Switch	Positive
Starter 1	Blue/White	At Ignition Switch	Positive
Accessory 1	Purple/Green	At Ignition Switch	Positive
Parklights Positive	Purple/White	At The SJB Connector "E" Pin 6	Positive
Parklights Negative	Gray (See Diagram)	At Lights Switch	Negative
Brake Lights	Purple/White	In Driver's Kick Panel	Positive
Horn	Blue/White	At Steering Column Harness	Negative
Tach	Odd Color	At Coil On Top Of Motor	1 Cylinder
Lock	Blue/Green	Drivers Kick Panel Or SJB Connector C Pin17 (1)	Negative
Unlock	Yellow/Purple	Drivers Kick Panel Or SJB Connector C Pin4 (1)	Negative
Trunk	Brown	At Switch Or SJB Connector C Pin20 (1)	Negative
Driver Door Unlock	Blue/Green	Drivers Kick Panel Or SJB Connector D Pin28 (1)	Reverse
E-Brake	White/Purple	At E-Brake Switch Or SJB Connector C Pin1 (1)	Negative
OEM Hood Switch	Blue/Orange	At SJB Connector F Pin10 (1)	Open
Disarm	Green/Purple	Drivers Kick Panel Or SJB Connector C Pin8 (1)	Negative
Rearming	Yellow/Green + Purple/Green	Drivers Kick Panel Or SJB Connector C (1) (2)	Negative
Dome Sensor	Gray/Purple	Drivers Kick Panel Or SJB Connector A Pin9 (1)	Positive
Trunk Pin	Gray/Orange	Drivers Kick Panel Or SJB Connector C Pin16 (1)	Open
KeySense	Blue/Gray	At Ignition Switch	Positive
Door Pin FL	Green/Purple	Drivers Kick Panel Or SJB Connector C Pin14 (1)	Open
Door Pin RL	Green	Drivers Kick Panel Or SJB Connector C Pin3 (1)	Open
Door Pin FR	White	Drivers Kick Panel Or SJB Connector C Pin2 (1)	Open
Door Pin RR	Yellow	Drivers Kick Panel Or SJB Connector C Pin15 (1)	Open
Fuel Pump	Purple/White	Driver's Running Board Harness	Positive
Rear Defogger	White/Orange	Back Of A/C Control Module (3)	Neg 8 Min.
Head Lights	Blue/White (See Diagram)	At Lights Switch	Negative
Auto lights OFF	Purple/Green	At Lights Switch	Open
Memory Seat 1	Purple/White	Driver's Running Board Harness	Negative
Memory Seat 2	Yellow	Driver's Running Board Harness	Negative
Wiper Protection	Black/Blue	At Wiper Switch	Open
BackUp Lights	Green/Brown	Driver's Running Board Harness	Positive
Transponder RX	Purple/Gray	At Transponder Module	Data
Transponder TX	Yellow/Orange	At Transponder Module	Data
Transponder Ignition	Blue/Tan	At Transponder Module	Positive

IM/OM Compatibility

- OM-Ford-3 (310-907-521) - OM-CUT-II (310-908-500) - OM-CUT-3 (310-907-516) - OM-FOT-1 (310-907-580) - 755T2
- 755T2 - XK04 - PKFORD - XK04 - PKF3

Comments on page 2

This data sheet is supplied as information purpose only. Astroflex does not, in any way, warranty accuracy of the data. Before attempting any installation or connections, the installer should verify all wires with either a multi-Meter or a high level probe that is computer and air bag safe. At all time, the installer assumes all damages, defects, or all other problems that could be linked to the installation process. ©Astroflex, 2003. All rights reserved.
La présente feuille de données est fournie à titre informatif seulement. Astroflex ne garantit d'aucune façon la justesse de ces données. Avant de procéder à l'installation ou de faire tout branchement, l'installateur doit vérifier tous les fils à l'aide d'un multimètre ou d'une sonde à haute impédance sécuritaire tant pour l'ordinateur que le coussin gonflable du véhicule. L'installateur assume en tout temps, l'entière responsabilité de tous dommages malfaçons ou autre résultant de l'installation. ©Astroflex, 2003. Tous droits réservés.

Ford Taurus 2008

Comments :

Note: This car is equipped with a transponder immobilizer system that need to be bypassed.

(1) The SJB (Smart Junction Box) is located in the driver's kick panel.

(2) These 2 wires are the driver's door keypad #7/8 (Purple/Green) and 9/0 (Yellow/Green). Pressing these 2 buttons lock and arm the system.

Pulse the two wires at the same time, isolated with two diodes. At the SJB, the wires are at Pin 6 (Yellow/Green) and Pin 18 (Purple/Green).

(3) For manual climate control, the wire is located on connector #1 pin3. For automatic climate control, the wire is located on connector #2 pin23.

This data sheet is supplied as information purpose only. Astroflex does not, in any way, warranty accuracy of the data. Before attempting any installation or connections, the installer should verify all wires with either a multi-Meter or a high level probe that is computer and air bag safe. At all time, the installer assumes all damages, defects, or all other problems that could be linked to the installation process. ©Astroflex, 2003. All rights reserved.

La présente feuille de données est fournie à titre informatif seulement. Astroflex ne garantit d'aucune façon la justesse de ces données. Avant de procéder à l'installation ou de faire tout branchement, l'installateur doit vérifier tous les fils à l'aide d'un multimètre ou d'une sonde à haute impédance sécuritaire tant pour l'ordinateur que le coussin gonflable du véhicule. L'installateur assume en tout temps, l'entière responsabilité de tous dommages malfaçons ou autre résultant de l'installation. ©Astroflex, 2003. Tous droits réservés.