



- Unlock and open a door. The alarm should sound immediately. You may now disarm.

### TotalRecall™

The system's non-volatile memory records the identity of the last eight activated or malfunctioning triggers and sensors, which allows you to instantly track down the source of a customer complaint about falsing. To identify the trigger or sensor stored in the system's non-volatile memory, do the following:

- With the **ignition off**, flick the PlainView switch to its **latched** side.
- Press remote control button 1 to arm and then again to disarm.
- The **LED will blink 1–3 times**, pause, then repeat. Refer to the **chart**:
- If the sensor is indicated, check the sensitivity. If a trigger was activated, check the pin switch operation and check the wire for possible shorting.

Number of blinks	Trigger/Sensor Identification
1 blink	Magnetic Resonance Sensor
2 blinks*	Door trigger*
3 blinks	Trunk or hood trigger

### User-selectable features

Sabre II comes from the factory with all of its features pre-programmed as noted in the table below. To change any of the settings, use the procedure noted. To restore the feature to its factory setting, just repeat the procedure:

- Select** the feature you wish to program from the table below. Note the number of momentary (spring-loaded) **taps**.
- Turn the **ignition on**, then enter the **valet code** (the single digit 2) by tapping the PlainView switch's momentary side twice, then press to latched (the LED will turn on to indicate programming mode).
- Immediately tap and release the **momentary** side of the switch the **number of times indicated** in the third column of the programming table for the feature you selected (to help you count, you will hear a single chirp confirmation each time you tap the momentary side).
  - If noted, immediately perform the "**secondary action**."
- Wait** for the program completion confirmation (1-4 chirps and the LED will turn off), then turn the **ignition off**.
- Repeat steps 1-4 for any other features you wish to program.

Feature	Factory setting	# of momentary taps	Secondary action	Program completion confirmation	Result
AutoArming	ON	4	—	1 chirp = OFF 2 chirps = ON	Change state from ON to OFF or vice-versa
AutoArm & Lock	OFF	5	—	1 chirp = OFF 2 chirps = ON	Change state from OFF to ON or vice-versa
False Alarm Control and Test	ON	6	—	1 chirp = OFF 2 chirps = ON	Change state from ON to OFF or vice-versa
Arm/disarm chirp confirmations	ON	9	—	1 chirp = OFF 2 chirps = ON	Change state from ON to OFF or vice-versa
Add a new remote to channel 1 (arm/disarm)	—	11	Press remote control button 1	1 chirps	Button 1/channel 1 code of the new remote control has been memorized
Add a new remote to channel 2 (optional accessory)	—	12	Press remote control button 2	2 chirps	Button 2/channel 2 code of the new remote control has been memorized
Add a new remote to channel 3 (silent arm/disarm)	—	13	Press remote control button 3	3 chirps	Button 3/channel 3 code of the new remote control has been memorized
Erase all channels	—	15	—	2 chirps	All channels have been erased, program new remote control(s) into channels 1-3
Valet code	<b>This feature should be set only by the vehicle owner.</b>				
Starter/ignition interrupt relay (normally closed/open)	CLOSED	20	—	1 chirp = open 2 chirps = closed	Change relay from NORMALLY CLOSED to NORMALLY OPEN or vice-versa